



SHADE SAILS

/ PRODUCT CARE AND USE

Please follow these product care instructions. Our aim is to provide you with years of hassle-free weather protection with very little maintenance. Failure to follow these will void your warranty.



**MAKING
SHADE**

CLEANING

Your Shade Sail may become dirty over time. To ensure the life-span of the Shade Sail fabric we recommend gentle cleaning from time to time.

- Care should be taken to avoid using any chemicals that may attack the UV stabilisers within the Shade cloth.
- We recommend the use of standard household dish washing detergent and the use of a low-pressure water hose. Apply the solution with a sponge or very soft brush.
- The fabric should NOT be washed in the washing machine, scrubbed with a stiff brush, scouring pad or the use of any abrasive cleaners.
- The use of high pressure water to blast the fabric clean is not recommended.

REMOVAL AND STORAGE

- If you remove the Shade Sail over Winter, ensure that it is dry before being stored.
- Preferably store the Sail in a protective bag away from rodents.

SERVICE

Don't forget we offer a Product Service. This service checks the operation of your product, including the condition of the fabric and stitching. If you feel your Making Shade product could benefit from a health check please get in touch with the Making Shade Team.

SHADE SAILS / LOUVRE SHADE
ZIPTRAK® BLINDS / RETRACTABLE AWNINGS

36f MacDonald Street / Mount Maunganui / 3116
07 572 5509 / info@makingshade.co.nz
WWW.MAKINGSHADE.CO.NZ



MAKING
SHADE

Creating outdoor living spaces